
























PASSARULLI / ROLLER PASSAGES

SG-T000001 	SG-T000007 	SG-T000013-5F 	SG-T000019-4F 
SG-T000002-5F 	SG-T000008 	SG-T000013-6F SG-T000014 	SG-T000019-5F SG-T000020 
SG-T000002-4F SG-T000003 	SG-T000009-3F 	SG-T000015-4F 	SG-T000021 
SG-T000004 	SG-T000009-6F SG-T000010 	SG-T000015-5F SG-T000016-3F 	SG-T000022 
SG-T000005 	SG-T000011 	SG-T000016-4F SG-T000017-5F 	SG-T000023 
SG-T000006-7F 	SG-T000012-3F 	SG-T000017-6F SG-T000018-4F 	
SG-T000006-8F	SG-T000012-4F	SG-T000018-5F	

ELENCO CODICI PASSARULLI CODE LIST ROLLER SUPPORTS

CODICE CODE	DESCRIZIONE DESCRIPTION	PESO WEIGHT m / l
SG-T000001	Passarulli passo / Roller support step 34,42 (R1) H=91	16,6
SG-T000002-4F	Passarulli passo / Roller support step 42,85 (R2) 4f H=91	16,2
SG-T000002-5F	Passarulli passo / Roller support step 42,85 (R2) 5f H=91	20,5
SG-T000003	Passarulli passo / Roller support step 46,66 (R3) H=91	33,5
SG-T000004	Passarulli passo / Roller support step 48 (R4) H=82	13
SG-T000005	Passarulli passo / Roller support step 48,8 (R5) H=82	16,3
SG-T000006-8F	Passarulli passo / Roller support step 48.83 (R6) 8f H=91	35,5
SG-T000006-7F	Passarulli passo / Roller support step 48.83 (R6) 7f H=91	31
SG-T000007	Passarulli passo / Roller support step 50 (R7) H=82	14,5
SG-T000008-7F	Passarulli passo / Roller support step 56,75 (R8) 7f H=115	51
SG-T000008-6F	Passarulli passo / Roller support step 56,75 (R8) 6f H=115	43,65
SG-T000009-3F	Passarulli passo / Roller support step 60 (R9) 3f H=82	10,21
SG-T000009-6F	Passarulli passo / Roller support step 60 (R9) 6f H=82	21,3
SG-T000010	Passarulli passo / Roller support step 60 (RA) H=91	23,11
SG-T000011	Passarulli passo / Roller support step 60 (RM) H=100	25,55
SG-T000012-4F	Passarulli passo / Roller support step 60 (RQ) 4f H=100	21,18
SG-T000012-5F	Passarulli passo / Roller support step 60 (RQ) 3,5f H=100	17,94
SG-T000013-6F	Passarulli passo / Roller support step 60 (RG) 6f H=115	45,47
SG-T000013-5F	Passarulli passo / Roller support step 60 (RG) 5f H=115	37,8
SG-T000014	Passarulli passo / Roller support step 67,7 (RC) H=82	17,2
SG-T000015-4F	Passarulli passo / Roller support step 67,7 (RB) 4f H=91	16,3
SG-T000015-5F	Passarulli passo / Roller support step 67,7 (RB) 5f H=91	19,3
SG-T000016-4F	Passarulli passo / Roller support step 67,74 (RR) 4f H=100	23,26
SG-T000016-3F	Passarulli passo / Roller support step 67,74 (RR) 3,5f H=100	19,27
SG-T000017-5F	Passarulli passo / Roller support step 67,74 (RL) 5f H=115	43,15
SG-T000017-6F	Passarulli passo / Roller support step 67.74 (RL) 6f H=115	51,85
SG-T000018-4F	Passarulli passo / Roller support step 72,41 (RS) 4f H=91	20,54
SG-T000018-5F	Passarulli passo / Roller support step 72,41 (RS) 5f H=91	25,75
SG-T000019-4F	Passarulli passo / Roller support step 72,41 (RT) 4f H=100	22,19
SG-T000019-5F	Passarulli passo / Roller support step 72,41 (RT) 4.5f H=100	24,02
SG-T000020	Passarulli passo / Roller support step 84 (RU) H=100	28,65
SG-T000021	Passarulli passo / Roller support step 100 (RE) H=124	32,72
SG-T000022	Passarulli passo / Roller support step 120 (RP) H=110	39,36
SG-T000023	Passarulli passo / Roller support step 120 (RF) H=124	45,6

